PHOENIX
DESIGN & MANUFACTURING, LLC.

Flap Weights

Phoenix Design & Manufacturing 6215 Aluma Valley Drive Oklahoma City, OK 73121 Toll Free 888-789-2550

Installation Procedure:

1. Align the Flap Weight on the mud flap in the desired position, and using the part as a template, mark the mounting holes on the mud flap.

2. Drill the holes in the mud flap with a 17/64” (.265”) drill bit.

3. Install the bolts, sandwiching the mud flap between the Flap Weight and back plate. Use the provided washer and nylock for each bolt and tighten.

WARNING: Do not over tighten the bolts as this may deform the product.

P 521007 Rev A

CAUTION: Sheet metal parts may have sharp edges